

Roland Classroom Activity: RM700 Piano

Lesson: Recital Slide Show

Concepts: Reinforce and celebrate during recitals

Grades: all grades and levels

Preparation:

Note: This slide show is intended to be created in advance and saved to a USB key in advance of the recital. If using a camera, simply connect the USB cable that comes with your camera into the host port on the RM700 and start at step 5 below.

National Standards Met:

Standard 8: Understanding relationships between music, the other arts, and disciplines outside the arts.

Standard 9: Understanding music in relation to history and culture.

Detailed Lesson Plan:

To create a slide show from a USB Memory Key:

1. Use a USB key with nothing else stored on it.
2. Create a folder on the USB key called “_PICTURE”
3. Select desired photos and save in the “_PICTURE” folder
4. Insert the USB key into the host port on the RM700.
5. Select the SONG you wish to play and press PLAY.
6. Press SLIDE SHOW.

Notes:

You must press PLAY before the SLIDE SHOW will start.

Using an external monitor like a flat screen tv or projector will enhance the recital setting slide show.